


SPARES FOR STONE CRUSHERS

We produce spares and wear parts for most of the commonly used crushing equipments. Our range of products includes High Manganese and High Carbon High Chrome (HiC HiCr) alloy castings for wear parts. We also deal in centrifugally cast bronze alloy for critical spares like Eccentric/Frame Bushings and Thrust Bearings.

JAW CRUSHER PARTS



Fixed/Swing Jaw Plates

CONE CRUSHER PARTS



Mantle/Concave/Bowl Liners



Head Nuts
Dust Seal Rings
Frame Bushings
Eccentric Bushes
Filters & Breathers
Thrust Bearing Sets



Springs
Toggle Seats
Toggle Plates
Hammer Screws
Protection Plates
Tightening Wedges
Anti-Vibration Pads

HSI PARTS



Hammers
Blow Bars

VSI PARTS



Rotor Tips
Back Up Tips
Feed Eye Rings
Distributor Plates
Rotors, Feed Tubes
Tip Cavity Wear Plates
Upper/Lower Wear Plates
Top Wear Plates & Trail Plates

REPLACEMENT PARTS SUITABLE FOR METSO, NORDBERG, SANDVIK, PUZZOLANA, NAWA, TEREX PEGSON, FINLAY, LORO PARISINI, KEUKEN, ECOMAN, EXTEC, PARKER, L&T, BERGEAUD AND OTHERS